

**RESTORE A 7E BACKUP FLOPPY DISK
INTO A 7E USB CARD CAGE
DOCUMENTATION**



Thursday, December 10, 2009
Prepared by: Michael Martinet

100 Avon Street, P.O. 1547
CHARLOTTESVILLE, VA 22902

Phone: +1 (800) 247-9796

Fax: +1 (434) 295-7799

Email: nopsales@nationaloptronics.com

PREPARE THE 7E USB TOOLS FLASH DRIVE**1. Download the latest software version**

1. Go to <http://www.nationaloptronics.com>
2. Go to the menu *Customer Support >> Software Downloads*.
3. Click on the link *7E Software (USB)* to save the file on your computer.

2. Create the USB installer flash drive

4. Insert a USB flash drive on your computer.
5. Wait until the flash drive has been correctly installed by Windows.
6. Execute the file you just downloaded.
7. Follow the installation wizard to create the flash drive.



If it's the first time you have used this flash drive to install the 7E USB tool, the flash drive will be formatted. In this case you will lose all data saved on the flash drive.



Don't use the BACKUP flash drive shipped with the machine. This thumb drive contains the default factory setup. Don't use it to back up or update the machine. Use a new USB flash drive.

If you have received an External USB Floppy drive, go to the section "Restore with an external USB Floppy Drive".

If your computer has a USB port and a Floppy Drive, go to the section "Restore with your computer".

3. Choose your configuration**RESTORE WITH AN EXTERNAL USB FLOPPY DRIVE**

1. Connect the External USB Floppy Drive into the back of the 7E machine.
2. Plug the "7E USB Tools" flash drive into the back of the machine.
3. Switch ON the 7E. Wait until you see a menu on the screen.
4. Select *Restore from floppy disk* and press <enter>.
5. Insert the "Backup disk" into the floppy drive and press any key to continue.
6. Wait until all operations are done.
7. Remove the USB flash drive.
8. Unplug the External USB floppy drive.
9. Restart the machine.

RESTORE WITH YOUR COMPUTER**1. On your computer**

1. Insert the "Backup disk" into the floppy drive of your computer.
2. Insert the "7E USB tools" flash drive into a USB port of your computer.
3. With Windows Explorer, copy all files from the floppy drive to the *data* directory of your flash drive.
4. Correctly unmount the flash drive.

2. On the 7E

5. Plug the "7E USB tools" flash drive into the back of the machine.
6. Switch ON the 7E. Wait until you see a menu on the screen.
7. Select *Restore System* and press <Enter>.
8. Remove the USB flash drive.
9. Restart the machine.